# Product Guide



# UHS7

### **Infrared User Handset**

### Overview



The UHS7 is a compact infrared handset used for:

- Selecting scenes.
- Raising and lowering the scene light levels.
- Turning the lights on or off.

### **Pointing the Handset**

You must point the handset directly at the device that you want to control.

### **Care and maintenance**

#### Replacing the Battery

The battery compartment is located on the bottom edge of the handset.

Release the retaining lug to allow the battery holder to be slid out.

Lift out the battery from the holder and insert a replacement battery (type CR2025 or equivalent), ensuring correct polarity.

Slide the holder back into the handset, ensuring that the retaining lug clicks into place.

#### **Cleaning the Handset**

The exterior of the handset can be cleaned by using a damp cloth. Stubborn marks may be removed by using a mild detergent.

Accessing the internal battery





## Technical data

86mm x 4mm x 67mm **Dimensions** 

Weight 0.017kg

3Vdc lithium battery **Battery** 

CR2025 (supplied with unit)

IR range 7m

Temperature 0°C to 35°C

Humidity 5 to 95% non-condensing

Compliance EMC-2004/108/EC





If any of these symbols are on the product or battery, the product or battery must be disposed of in the correct manner and must not be treated as household

or general waste.









C.P. Electronics Ltd Brent Crescent London NW10 7XR United Kingdom

United Kingdom
Tel: +44 (0) 333 900 0671
Fax: +44 (0) 333 900 0674
www.cpelectronics.co.uk
enquiry@cpelectronics.co.uk